

Grid Kit

Mounting instruction



About Grid Kit

The versatile Grid Kit is designed to make it easy to control straylight and add contrast.

The kit includes two different grids that reduce light spread to either 10° or 20°. Both are fastened onto the flash with a smart magnetic mount.

With a grid fastened onto your flash, you get a direct, circular shape of light that you can use for many creative effects such as accent light, hair light or intriguing background effects.

**Get started with
your new Grid Kit**



1 Select a grid.



2 Fasten the grid onto the flash lens with just one click.



3 Done!



4

If you combine the grid with a gel, always fasten the gel first and stack the grid on top.

**For more information and inspiration:
profoto.com**